LifeFitness

Classic Recumbent Bike CLSR-0XXX-01



Customer Support Services
PARTS MANUAL

rev 18 Jan 2010

Miscellaneous 3
Console Components.....4
Console Support Assembly 5
Shrouds, End Cap, Crank Arms, and Pedals 6
Belts and 6V Battery 7
Resistor Assembly 8
Power Control Board.....9
Alternator w/Pulley 10
Crankshaft and Bearing Assembly 11
Intermediate Shaft and Bearing Assembly 12
Idler Bracket Assembly 13
Seat Assembly 14
Seat Bottom Assembly.....15
Seat Frame Assembly 16
Seat Pads and Accessory Tray 17
Extrusion Assembly.....18
Seat Locking Assembly 19
Wheel and Leveler 20
Cables 21

Description	Part No.
OPERATION MANUAL	M051-00K39-A167
POWER OPTION KIT 120V	GK39-00002-0002
POWER OPTION KIT 240/50V UK	GK39-00002-0004
POWER OPTION KIT 240V+AUS	GK39-00002-0005
POWER OPTION KIT 230/50V CON	GK39-00002-0006
HARDWARE BAG	GK39-00002-0008
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	 0017-00008-0204 0017-00008-0205 0017-00008-0206
SERVICE MANUAL	M051-00K39-A012



Language	Part No.	
	Console Assembly	Overlay/Bezel/ Switch Assembly
Eng	AK39-00133-0001	AK63-00165-0001
Eng Met	AK39-00133-0002	AK63-00165-0001
Ger Met	AK39-00133-0003	AK63-00165-0003
Spn Met	AK39-00133-0004	AK63-00165-0004
Jap Met	AK39-00133-0006	AK63-00165-0006
Frn Met	AK39-00133-0007	AK63-00165-0007
Itl Met	AK39-00133-0008	AK63-00165-0008
Dut Met	AK39-00133-0009	AK63-00165-0009


Console Mounting Screws (4)
0017-00101-1744
Grips (2)
0K39-01005-0001
Console Support
AK39-00003-0002
Frame Post Bolts (4)
0017-00101-1756
Frame Post


Right Shroud
AK39-00136-0000
Decal
0K39-01109-0000
Shroud Screws (7)
0017-00101-1741
Crank Arm, RT
0K39-01042-0009
Screws (3)
0017-00101-1855
End Cap Screws (2)
0017-00101-1614
End Cap
AK39-00050-0005
Decal
0K51-01085-0001
Right Pedal
AK63-00263-0003
Pedal Strap (not shown)
0K63-01238-0003
Shroud Screws (4)
0017-00101-1741
Left Shroud
AK39-00137-0000
Decal
0K39-01109-0000
Left Pedal
AK63-00263-0004
Pedal Strap (not shown)
0K63-01238-0004
Crank Arm, LT
0K39-01042-0010
Screws (3)
0017-00101-1855


Intermediate
Pulley Belt
0K63-01066-0001
Screw
0017-00101-1193
Mounting Screw(2)
0017-00101-0975
Bracket
0K51-01036-0000
Screw
0017-00101-1193
Alternator Belt
0017-00009-0735
6V Battery
0017-00003-0685

Resistor Assembly
AK39-00020-0001



Power Control Board Assembly
AK39-00022-0001



Alternator w/Pulley Assembly
AK63-00093-0000




Crank Arm Hub
0K63-01095-0001
Pulley Assembly
AK63-00051-0000
Pulley
0K63-01018-0000
Washers (3)
0017-00104-0458
Flywheel Screws (3)
0017-00101-1715
*Crankshaft & Bearing Kit
GK63-00002-0077
*Crankshaft
0K63-01012-0001
*Small Thrust Washer (2)
0K63-01129-0000
*Large Thrust Washer (2)
0K63-01129-0001
*Bowed Retainer Ring (2)
0017-00100-0243
Washer (2)
0017-00104-0409
*Needle Bearing (2)
0K63-01344-0000
*Small Snap Ring (2)
0017-00100-0241
Crank Arm Hub (2)
0K63-01095-0001
Bolt (2)
0017-00101-1705

Intermediate Shaft and Bearing Assembly GK63-00002-0007



Idler Bracket Assembly
AK63-00021-0000




Screws (4)
0017-00101-1745
End Caps (4)
0K19-01208-0001
Washers (8)
0017-00104-0461
Double-sided
Foam Tape (2)
0K19-01222-0000
Heart Rate Electrode
AK63-00014-0003
Handlebar w/Insert
AK39-00024-0002
Bushing Hole
0017-00042-0866
Screws (2)
0017-00101-1282
Seat Assembly
AK51-00023-0004
Tape (2)
0K19-01222-0000
Upper Flex Cable Clamp
0K19-01221-0000
Flat-Flex Cable
AK19-00082-0001
Cable Sleeve
0K19-01230-0000
Hex Bolts (4)
0017-00101-1749


Roller Shields (4)
0K51-01059-0001
Spacers (4)
0K51-01044-0000
Washer
0017-00104-0461
Locking Nuts (4)
0017-00103-0326
Washers (4)
0017-00104-0463
Washers (4)
0017-00104-0462
Screws (2)
0017-00101-1748
Lock Assembly
AK51-00053-0001
Bolts (4)
0017-00101-1743
Locking Nuts (8)
0017-00103-0325
Roller Assembly
AK51-00056-0001
Rollers, LT (2)
0K51-01034-0002
Rollers, RT (2)
0K51-01034-0001


Seat Assembly Frame
AK39-00036-0002
Screws (4)
0017-00101-1746
Washers (4)
0017-00104-0462
Front Stop Bracket
0K51-01062-0000
Plastic Shield
0K19-01185-0001
Split Clamp
0017-00042-0880
Pan Screw
0017-00101-1295
Push Mount Wire Clips (2)
0017-00042-0879


Accessory Tray
AK39-00052-0003
Seat Back
0K51-01055-0001
Seat Bottom
0K51-01054-0001
Washers (4)
0017-00104-0462
Mounting Screws (4)
0017-00101-1743


Seat Extrusion Assembly
AK39-00027-0005
Bumper
0017-00041-0654
Stop Bracket
0K51-01061-0001
Screws (2)
0017-00101-1751
Locking Rack
0K51-01013-0002
Screws (2)
0017-00101-1750
Decal
0K51-01039-0001
Plastic Grommet2 (2)
0017-00042-1055
Bolts (2)
0017-00101-1183
Extrusion Assy.
AK39-00029-0001

Locking Assembly
AK51-00053-0001




Rear Stabilizer
GK39-00002-0012
End Cap
0K63-01219-0001
Lock Nut
0017-00103-0273
Leveler
0017-00009-0795
Leveler Assembly
AK61-00035-0000
Pan Screws (2)
0017-00101-1747
Flat Washer
0K63-01041-0000
Wheel Assembly
AK63-00016-0001
Wheel Screw
0017-00101-1747
Wheel Insert
0K63-01039-0000



Cable Coax - AK32-00020-0001
Cable Power Ext - AK32-00078-0001